





## **FEATURE**

- 1. Smart and personality, fingerprint to control
- 2. Biometric fingerprint reader , more sensitive and responsive, up to 20 fingerprints can add
- 3. Easy to operate, put the finger on then lock open
- 4. Automatically motorized locking mechanism, integrated with LED light, motorized mechanism, bolt and battery case.
- 5. Low power, Low battery warning, Micro-USB port for emergency charging.

### FACTORY SETTING

FINGERPRINT: NONE, ANY ONE CAN OPEN THE LOCK, PLEASE ADD FINGERPRINT BEFORE USING

# STEP 1 ADD OR REMOVE FINGERPRINT

- 1. ADD FINGERPRINT
- →Press reset button, a (1) beep, blue light on in the circular indicator
- →Put a finger on the reader, a (1) beep, green light on, remove the finger
- →Put the same finger on the reader when blue light on, repeat the same operation for five times
- →Two beeps, green light on, fingerprint added
- 2. REMOVE FINGERPRINT
- ightarrowPress reset button for 4 sec
- ightarrowA (1) long beep, then two (2) beeps, system initialized, all the fingerprint remove
- 1) Make sure your belongs security, please remove all the fingerprint firstly and then add new fingerprint before using.
- 2) When failed to add fingerprint, three (3) beeps, repeat the steps and try again.
- 3) 20 fingerprint is added fully. When adding fingerprint, system will log out, it indicates the database is full. Remove the fingerprint firstly if new ones need to add.

## STEP 2 Lock and Unlock

- →Push door closed, put valid fingerprint on the reader, door locked automatically
- ightarrowPut valid finger on the reader for 2 sec
- →Two (2) beeps, door open automatically

### Note:

3) Consecutive five (5) invalid fingerprint will initiate burglar alarm for 1 min. It will suspend if putting valid fingerprint on

## BURGLAR ALARM

ightarrowDoor locked, press "#", burglar alarm initiated.

### LOW BATTER WARNING

→Door opened, "BATTERY" light flashes for six (6) time indicate low battery, replace the battery in time

Note: Outer battery case can use for emergency opening in case that it can't open the lock due to low battery.











